

The blaugelb FLK Sealing System – specifically for sealing elements near the ground.



blaugelb FLK Bucket 2.5 L

The handy helper for processing the blaugelb FLK Sealing System.

- **With a handle for easy processing**
- **Volume tailored to the successive portions**
- **Makes it unnecessary to carry large product containers**
- **Mobile work with light weight**
- **Robust plastic**

blaugelb FLK Bucket 2.5 L

The handy helper for processing the blaugelb FLK Sealing System.



Product features:

The blaugelb FLK Bucket is used to portion the liquid plastics blaugelb FLK Liquid and blaugelb FLK Liquid Corner during processing.

The blaugelb FLK Bucket is made of robust plastic and has a volume of 2.5 litres, perfect for conveying the blaugelb liquid plastics onto the hand tool with which the sealing is performed.

The compact dimension of the blaugelb FLK Bucket makes it easier to work near the ground and in hard-to-reach areas such as corners and grooves.

Product benefits:

- With a handle for easy processing
- Volume tailored to the successive portions
- Makes it unnecessary to carry large product containers
- Mobile work with light weight
- Robust plastic
- The filling height of 50 mm corresponds to approx. 900 g of liquid plastic

Technical data:

Material:	Plastic (PE-LD)
Contents:	2.5 litres
Colour:	White

Product name	PU	Item no.
blaugelb FLK Bucket 2.5 L	1 piece	9143751

Preparation and processing:

After stirring in the original container, the blaugelb FLK Liquid or blaugelb FLK Liquid Corner is poured into the blaugelb FLK Bucket. Dip the blaugelb FLK Brush or blaugelb FLK Roller into blaugelb FLK Bucket and cover it well with the liquid plastic material, then spread it on the substrate to be sealed.

For the individual processing steps, please refer to the detailed installation instructions for the blaugelb FLK Sealing System. This can be downloaded on the product page at www.blaugelb.de. The processing must always comply with the specification of the installation instructions.

Cleaning and repair:

The blaugelb FLK Bucket is a disposable item. Before curing, the blaugelb FLK Liquid and blaugelb FLK Liquid Corner can be cleaned with blaugelb Cleaner PVC-S10 UVA; after curing these can only be removed mechanically.

Delivery and storage form:

Store in its original packaging, cool and dry. Protect from sunlight, moisture, frost and heat. Shelf life unlimited at storage temperatures between +5 °C and +35 °C.

Disposal:

The blaugelb FLK Bucket is a disposable item. The disposal conforms with the national and local specifications.

Safety note:

The product is not classified as hazardous according to the regulation (EC) No. 1272/2008 (CLP). Only for trade use. Perform adequate pretests on compatibility and effect.